

SONY®



PS VITA™

PlayStation®Vita

Card case / Wrist strap / Cloth Instruction Manual

PCH-ZGC1 / PCH-ZWS1 / PCH-ZCC1

Compatible hardware: PlayStation®Vita system



Carefully read the information on this package together with the instructions for your hardware before using this product.

Card case

Use and handling

Organize and protect your PlayStation®Vita cards and memory cards with the official card case.

- Holds up to 8 game cards and 2 memory cards
- Protective clam shell design




Wrist strap

Use and handling

Ensure your PS Vita is secure wherever you play

- Attach a strap as shown below.



Cloth

Use and handling

- Keep your PS Vita clean and free from dust or dirt.
- Hand wash the cloth with detergent. Do not dry the cloth in direct sunlight.



The manufacturer of this product is Sony Computer Entertainment Inc., 1-7-1 Konan, Minato-ku, Tokyo 108-0075 Japan.


Distributed in Europe by Sony Computer Entertainment Europe Ltd, 10 Great Marlborough Street, London, W1F 7LP, United Kingdom.

Limitations of Liability

Other than as expressly set forth by Sony Computer Entertainment Europe Limited (“SCEE”) or any other Sony entity, or their suppliers or authorised service facilities, except to the extent prohibited by applicable laws, SCEE or any other Sony entity, or their suppliers or authorised service facilities, shall not be liable for any damages, including special, incidental or consequential damages, or fees arising out of the use or inability to use this product.

Design and specifications are subject to change without notice.

“PS” and “PlayStation” are registered trademarks of Sony Computer Entertainment Inc. “PS VITA” is a trademark of the same company.

“SONY” and “” are registered trademarks of Sony Corporation.



eu.playstation.com/psvita